



What does screw air compressor fault code c01 mean

What is a compressor fault code?

Following, are the descriptions of the COMPRESSOR fault codes. These are indicated by the SECU Display Digit. S3 is located in the discharge pipe from the airend. The SECU has detected an open S2, compressor separator tank temperature Switch. Machine could be overheated or have a faulty switch or wiring.

What is a rotary screw compressor?

A Rotary Screw Compressor is an industrial air compressor that uses rotating screws to compress air. These compressors can run multiple applications and tools depending on the job site and requirements. They are available in various sizes, from 28 to 250 cfm.

What happens if the air compressor displays an error or shutdown?

When the compressor displays an error or shutdown, the conditions of the error will automatically reset once the condition has been resolved, and the air compressor has restarted and works with no issues.

What do enclosed hydraulic-driven rotary screw compressors operate on?

Enclosed Hydraulic-driven Rotary Screw compressors operate on fluid power to run multiple applications and pneumatic tools. Cube Air System Rotary Screws provide the same efficiencies and reliability as open screw compressors for those with space parameters or existing air storage.

What is the range of cfm for the offered rotary screw compressors?

Gas & Diesel Engine-driven Industrial Rotary Screw compressors can run multiple applications and tools depending on the job site and requirements. Units from 28-250 cfm. Cube Air System Rotary Screws provide the same efficiencies and reliability as open screw compressors for those with space parameters or existing air storage.

How does a screw compressor work?

A screw compressor can run loaded ('pumping air') or unloaded ('idle'). The inlet/loading valve opens and closes according to air demand. The inlet valve is controlled by a solenoid valve that supplies control air to the inlet/loading valve. Check solenoid valve coil and solenoid valve operation.

Discover the significance of discrepancies in air/oil cooler temperatures and how these variations provide crucial insights into equipment performance and potential issues.

If your Ingersoll Rand air compressor is not building pressure or not turning on, troubleshooting common issues such as a defective reed valve or low oil levels can help ...

Kaeser air compressors use specific fault codes to signal issues, with codes like P1 indicating high pressure,

What does screw air compressor fault code c01 mean

and can be found in the Kaeser compressor troubleshooting pdf ...

Troubleshooting air compressors? Here are some common problems that can develop in a compressed air system and probable causes and suggested actions.

The main reason for screw air compressor failure C01 refers to host imbalance, which means that the three-phase voltage of the host is unbalanced. This fault ...

Your air compressor will show enough symptoms before breaking down. These symptoms, if not attended on time, can lead to erratic behaviour, inefficient compression ...

The compressor includes a coolant level decal which shows the proper level range appropriate for operation. When the coolant level sight glass at the level indicated by the green area on the ...

Machine could be overheated or have a faulty switch or wiring. S2 is located in the side of the separator tank. The SECU has detected a low alternator/battery voltage. It is below 11.6V. The ...

Your air compressor will show enough symptoms before breaking down. These symptoms, if not attended on time, can lead to erratic behaviour, ...

A. A. Air absorbing process The air inlet design of the screw compressor can make the compressing chamber absorb air absolutely. The air suction is only adjusted by on-off of the ...

Provided below is a general list of common air compressor problems, and a few quick fixes that may help solve your dilemma. There are also many links to ...

This article consolidates industry technical manuals and front-line maintenance experience to help quickly identify and resolve common faults in screw air ...

When the compressor displays an error or shutdown, the conditions of the error will automatically reset once the condition has been ...

The built-in after-cooler reduces the discharge air temperature below the dew point (for most conditions). Therefore, considerable water vapor is condensed. To remove this condensation, ...

How to deal with air compressor failure CO1? The main reason for screw air compressor failure C01 refers to host imbalance, which means that the three ...

Reasons Sullair Compressor Shows Fault Codes In the event of a system fault of some sort, the Sullair air compressor will likely display a fault ...



What does screw air compressor fault code c01 mean

The different fault state conditions are indicated on the screen with specific codes; the last character indicating the fault type: E = Shutdown Trip Error, A= Alarm, S = Start Inhibit, R = ...

Atlas Copco air compressors are a worldwide operating company, that provides a broad range of air compressor technology to users around the ...

Shanghai Denair Compressor Co.,Ltd. Double Screw Air Compressor Installation, Maintenance and Operation Manual Shanghai Denair Compressor Co., Ltd Add: Room301, No.18 ...

This list does not have the intention to provide a full on explanation and resolution for each fault code. To learn more about the specific issue you are encountering, please consult your ...

Rotary Compressor Troubleshooting Guide ... butor and servicer of compressed air systems. We believe you should be able to count on a reli ble compressor for years of trouble-free use. We ...

The troubleshooting table below is not comprehensive, but indicates some common problems that can develop in a compressed air system using positive displacement compressors.



What does screw air compressor fault code c01 mean